

Functional description



for the following LEIB CAN BUS modules (only for BMW F - models):

- LEIB CAN BOOST

Table of contents

Disclaimer	3
Function description LEIB CAN BOOST.....	4
Contact information.....	5

Disclaimer

No guarantee for correctness and accuracy of the information contained herein can be given by LEIB Engineering GmbH & Co. KG. Liability claims against LEIB Engineering GmbH & Co. KG, which refer to material or ideational kind of damages by using or not using the information or rather by using incorrect and incomplete information are basically excluded, in case of demonstrable negligent or grossly negligent fault on the part of LEIB Engineering GmbH & Co. KG. Die LEIB Engineering GmbH & Co. KG formally reserves the right, to change, to add, to delete parts of the pages or the whole offer without separate announcement or to suspend the publication temporary or finally.

Function description (Boost gauge)

The boost pressure is represented in the instrument cluster by the instantaneous consumption display in the ratio 1 : 10 (bar : L / 100 km).

Contact information

LEIB Engineering GmbH & Co. KG

Berggärten 5
35644 Hohensolms
Germany

Tel.: +49 (0) 641 - 1313221 - 0

Fax.: +49 (0) 641 - 1313221 - 9

info@leib-engineering.de

www.leib-engineering.de

www.facebook.com/leibengineering

www.instagram.com/leibengineering